





Cobra**AirWave**TM **Waterproof Bluetooth**[®] **Speaker**



Printed in China Part No. 480-933-P Version A

CWA BT310
**Product
Information Guide**

PRODUCT FEATURES



CARE AND MAINTENANCE

1. Never try to disassemble or service the product by yourself. Opening the unit will damage the seals that make it waterproof!
2. Keep the Cobra Airwave™ Box and accessories out of reach from children.
3. Do not expose the Cobra Airwave™ Box to temperatures above +55° C (+131° F). If the product is operated in extreme hot or cold temperature, the battery capacity is reduced. Use it at room temperature for maximum battery capacity.
4. The Cobra Airwave™ Box is waterproof and it can be cleaned by rinsing off or with a soft cloth and mild detergent.
5. Although the product is IPX7 compliant, it is not designed to be used for extended periods of time floating in water. Please make sure the rubber cover over the jack is closed tightly while around water. Retrieve and dry if the speaker is dropped in water.

CHARGING


The Cobra Airwave™ Box has a built-in Li-ion battery, so it can be used without connecting to a power supply. To charge the battery, follow these steps:

1. Connect the micro USB connector of the supplied USB cord to the Cobra Airwave™ Box micro-USB input.
2. Plug the USB full-size connector into a computer USB port, common USB type AC charger (DC 5V, 500mA) or any USB power source.

- When the device is charging the LED status indicator will be RED. When fully charged the RED status indicator LED will go off.
- A full charge will last for up to 10 hours of normal use.

OPERATION

Turning the Cobra Airwave™ Box On or Off



Multi-Function Key

Press and hold the Multi-Function Key for 2 seconds to turn On. The blue LED will turn on and blink. "**Power On**" will sound from the speaker. Press and hold the Multi-Function Key for 3 seconds to turn Off. The red LED will turn on then turn off. "**Power Off**" will sound.

Pairing the Cobra Airwave™ Box with a smartphone or any **Bluetooth**® enabled music device

To use the Cobra Airwave™ Box with any **Bluetooth**® enabled smartphone or media device, you must first pair the device to the Cobra Airwave™ Box. Once they have been paired for the first time, the phone or media device will automatically re-connect to the Cobra Airwave™ Box when the power is turned ON and **Bluetooth**® is enabled on your device. For additional information, see the operation manual for your smartphone or media device.

Pairing with smartphone

1. Turn **Bluetooth**® on in your settings menu. It will begin searching for any **Bluetooth**® device within range.
2. With power off, press and hold the Multi-Function Key for 5 seconds (keep holding when you hear "Power On" after 2 seconds) and the blue and red LEDs will alternately blink. "**Pairing**" will sound.
3. You will see the Cobra Airwave™ Box on the devices list on your phone. Select the **Cobra Airwave Box** to pair. Once connected, the blue LED light will blink on the Cobra Airwave™ Box and "**Successful**" will sound.

Playing music


To play music through the Cobra Airwave™ Box, first pair the devices. Music played on the **Bluetooth**® enabled smartphone or other **Bluetooth**® device will be played through the Cobra Airwave™ Box.

For smartphones and some other **Bluetooth**® devices pressing the Multi-Function Key will cause the paired device to start playing. Pressing the Multi-Function Key again will pause the audio.

The audio can also be started and paused using the smartphone controls.

ADJUSTING VOLUME

To increase or decrease the Cobra Airwave™ Box volume, press the "+" or "-" buttons.



- Volume can be adjusted with Cobra Airwave™ Box controls or the paired Bluetooth® device connected to the Cobra AirWave™ Box.

Pairing a new device with the Cobra Airwave™ Box

1. Use the smartphone or paired devices' Bluetooth® settings menu to unpair the Cobra Airwave™ Box.
2. Press and hold the Multi-Function Key for 3 seconds to turn off the Cobra Airwave™ Box.
3. Follow the steps under "Pairing with smartphone" to complete pairing.

Answer incoming call/hang up

If a call comes through in stand by mode or while playing music, click on the Multi-Function Key to answer the call. To hang up, press the Multi-Function Key again.

QUICK REFERENCE GUIDE

Mode	Controls	Action	Functions
Power	▶	Press & Hold >2s	Turn Power On/Off
	▶	Press & Hold >3s	Pair to Bluetooth® (from power off)
Music	▶	Press	Play/Pause Music
	+	Press	Volume Up
	-	Press	Volume Down
Phone	▶	Press	Answer Incoming Call
	+	Press	Volume Up
	-	Press	Volume Down
	▶	Press	End Call

FCC & INDUSTRY CANADA STATEMENT

For Products Purchased in USA:

NOTE: This device complies with part 15 of FCC rules: Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received including interference that may cause undesired operation.

CAUTION: Modifications or parts not approved by Cobra Electronics Corporation may violate FCC Rules and void authority to operate this equipment.

For Products Purchased in Canada:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

This equipment is portable device. The output power of this device is less than 20mW. The SAR test is not required.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

PRODUCT SERVICE QUESTIONS

For any questions about operating or installing this new Cobra product, or if parts are missing...**PLEASE CALL COBRA FIRST**...do not return this product to the store.

For Products Purchased in the U.S.A.

If your product should require factory service, please call Cobra first before sending your radio. This will ensure the fastest turn-around time on your repair. You may be asked to send your radio to the Cobra factory. It will be necessary to furnish the following to have the product serviced and returned.

- 1) For warranty repair include a copy of the original sales receipt. If you send the original receipt, it cannot be returned.
- 2) Send the entire product.
- 3) Enclose a detailed description of the problem along with the name and address of where the product is to be returned.
- 4) Pack radio securely to prevent damage in transit. If possible, use the original packing material.
- 5) Ship prepaid and insured by way of a traceable carrier such as United Parcel Service (UPS) or Priority Mail to avoid loss in transit to Cobra Factory Service:
Cobra Electronics Corporation
6500 West Cortland Street
Chicago, Illinois 60707 U.S.A.
- 6) If the radio is under warranty, it will be repaired or exchanged depending on the model.

Please allow approximately three to four weeks before contacting Cobra for status. If the product is out of warranty, a letter will automatically be sent informing you of the repair charge or replacement charge. If you have any questions, please call 773-889-3087 for assistance.

For Products Purchased Outside the U.S.A.

Please contact your local dealer for product service information.

LIMITED ONE-YEAR WARRANTY

For Products Purchased in the U.S.A.

Cobra Electronics Corporation warrants that its products and the component parts thereof, will be free of defects in workmanship and materials for a period of one year from the date of first consumer purchase. This warranty may be enforced by the first consumer purchaser, provided that the product is utilized within the U.S.A.

Cobra will, without charge, repair or replace, at its option, defective products, products or component parts upon delivery to the Cobra Factory Service department, accompanied by proof of the date of first consumer purchase, such as a duplicated copy of a sales receipt.

You must pay any initial shipping charges required to ship the product for warranty service, but the return charges will be at Cobra's expense, if the product is repaired or replaced under warranty. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

Exclusions: This limited warranty does not apply: 1) To any product damaged by accident; 2) In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs; 3) If the serial number has been altered, defaced, or removed; 4) If the owner of the product resides outside the U.S.A.

All implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty. Cobra shall not be liable for any incidental, consequential or other damages; including, without limitation, damages resulting from loss of use or cost of installation.

Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

For Products Purchased Outside the U.S.A.

Please contact your local dealer for warranty information.

Trademark Acknowledgement

Cobra®, Nothing Comes Close to a Cobra®, and the snake design are registered trademarks of Cobra Electronics Corporation, USA. Cobra Airwave™ and Cobra Electronics Corporation™ are trademarks of Cobra Electronics Corporation, USA.

The **Bluetooth**® word mark is a registered trademark owned by Bluetooth SIG, Inc. and any use of such marks by Cobra Electronics Corporation is under license.

©2014 Cobra Electronics Corporation
6500 West Cortland Street, Chicago, IL 60707
www.cobra.com