

2-PERSON TOWABLE TUBE

SF2PERTOW

Thank you for purchasing the Sunny & Fun® 2-Person Towable Tube. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty.

Please read all directions before using the product and retain this guide for reference. This product is intended for outdoor, domestic use only. It is not intended for commercial use.

This product is covered by a limited one-year warranty. Coverage is subject to limits and exclusions. See warranty for details.

SAFETY PRECAUTIONS

- Make sure to carefully read this user guide and all associated precautions and warnings before attempting to use this towable tube. Attempting to use this product without familiarizing yourself with the suggested usage guidelines and safety precautions could result in serious injury or death. **Use of this product and participation in this sport involves inherent risks of injury or death. To reduce these risks, adhere to the guidelines and precautions below.**
- Make sure to familiarize yourself with all applicable federal, state, and local laws; the risks inherent in water sports; and the equipment.
- Make sure that you know the waterways where you will be using this towable tube, and exercise caution and common sense.
- Never start out until the rider(s) signals that they are ready.
- Do not use this product at speeds that exceed the skills of the rider(s). For younger passengers, your boat speed should never exceed 15 mph (24 kph), and for adult passengers, the speed should never exceed 20 mph (32 kph).
- **USE THIS PRODUCT ONLY ON WATER.** Attempting land or dock starts can increase the risk of injury or death.
- This product should never be used by children except under adult supervision.
- This is not a personal flotation device. Do not attempt to use it as one.
- Always wear an approved personal flotation device suitable for the conditions and the waterway.
- Never place wrists, feet, or other appendages through the handles or towing harness. Make sure the rope is clear of all body parts prior to and/or during use of this towable tube.
- Rider(s) should be advised to keep their feet out of the water.
- This towable tube, by definition, affords no steering control to the riders. The watercraft driver is responsible for the ride, and should always have a secondary party to observe the safety and welfare of those passengers riding on the towable tube.
- The watercraft driver should avoid driving at excessive speeds or taking sharp turns, as these may cause the tube to flip over abruptly. This could result in serious injury to the rider(s) or present a drowning risk.
- Do not tow this tube in shallow water, or near shore, docks, pilings, swimmers, or other watercraft/boats.
- Do not exceed two (2) riders for this particular product.
- Make sure to use the tow rope provided, or make sure the tow rope you use has a tensile strength rated to support 1503 lbs.

(682 kg) to tow one person, or 2379 lbs. (1079 kg) to tow two people. The tow rope should be at least 50 ft. (15.25 m) in length, but not exceed 65 ft. (19.8 m). Again, a tow rope is provided for your convenience.

- Never operate a watercraft or ride on the towable tube while under the influence of alcohol or drugs.
- Only use your tube with a responsible driver who knows how to safely and properly operate the watercraft.
- Take all reasonable precautions in the use and operation of your tube and boat.
- Teach anyone using your tube how to attach it to the rope, how to ride it, and how to maintain it.
- Never strap or attach anyone to the tube or its cover.
- Never put your feet, hands, or other appendages through the strapping of the towing handles.
- Never wedge your hands, feet, or other appendages under the cover, or between the cover and the tube.
- Make sure the boat driver does not engage in reckless driving, or attempt to bounce the towable tube to make the passengers fall off. This is not a game and can result in serious injury, risk of drowning, or death.
- Make sure all slack is out of the tow rope before you accelerate the boat.
- The driver and tube rider must at all times watch for obstacles such as shore, pilings, docks, rafts, swimmers, or other boats, and the driver must be able to stop or turn to avoid these.
- Always ride the tube in control and at speeds appropriate for your ability. Know your own limits and use this tube responsibly.
- Stop when you or the rider(s) are tired. You should be in good physical condition and be cautious in your use of this or any other towable tube.
- Do not use this tube to go over ramps and jumps.
- Falling and the injuries that may result are inherent risks in this sport.
- Use a flag to signal to other boats and riders that a tube rider is in the water.

EQUIPMENT PRECAUTIONS

- Inspect all equipment prior to use. Make sure to check your personal flotation device (lifejacket, etc.) prior to each use as well.
- DO NOT USE if any parts or equipment are damaged.
- Tow ropes stretch during use. If a tow rope breaks, or is suddenly released, it can snap back, striking the boat occupants or tube riders, and can result in injury or death. Make sure your tow rope has a tensile strength rating sufficient to support towing your tube and its riders.
- Inspect all ropes and connectors for fraying, cuts, sharp edges, knots, or general wear and tear before each use. Do not use a damaged rope or connector, as these conditions can lead to breaks.
- Make sure to use the proper tow rope for this activity. Tow ropes designed for skiing are generally not compatible with towing an inflatable tube.
- Ensure the rope is clear of the rider(s) prior to starting out and/or during use.
- Keep all persons and ropes away from propellers at any point when the engine is running, even if it's idling. If the rope should become entangled in the propellers, immediately shut off engine and remove ignition key before retrieving the rope. Failure to do so could result in serious injury or death.
- Tow ropes and tubes are subject to deterioration when exposed to direct sunlight. Make sure to store this product and all accessories in a safe area out of direct sunlight.

BOX CONTENTS

- 2-person towable tube
- Air pump
- Tow rope
- User guide

Setting Up the Towable Tube

1. Remove the towable tube from its carry case or packaging.
2. Spread the nylon cover out on the floor and unzip the opening (when applicable).
3. Gently inflate the safety chamber or seats on the PVC tube (when applicable).
4. Insert the PVC tube through the zipper opening on the cover. Make sure to align the Stem Valve on the PVC tube with the round opening on the cover so you can fit the air pump attachment into the Stem Valve.
5. Grab the edge of the tube and the edge of the cover at the same time, then shake them up and down together (like you're

fluffing bedsheets). This will smooth out the PVC tube inside the cover and make sure the Stem Valve is properly aligned, which in turn makes inflation easier.

6. Zip the cover closed, making sure not to catch the PVC tube in the zipper.
7. Follow the instructions in the following sections, Setting Up the Air Pump, and Using the Stem Valve.
8. Inflate the main chamber of the tube using the included air pump or a similar high-volume, low-pressure pump.

Setting Up the Air Pump


1. Make sure that the air pump switch is in the OFF position. Plug the air pump into a 110 V outlet.
2. Set the power switch of the air pump to ON to inflate. If the air pump does not power on, press the reset button on the GCFI adapter.
3. After use, turn the power switch to OFF.

NOTES: Always set up the air pump as close to the power source as possible. The product should be periodically examined for potentially unsafe conditions such as: damaged cord, plug, housing or parts, and that in the event such damage is found, the product should not be used until properly repaired.

Never leave the air pump outside in the rain or exposed to the elements when not in use. When in use, do not place the cord across traffic areas, water, or damp areas. The air pump should be placed on a stable surface and anchored per product instructions.

Using the Stem Valve

Your towable tube comes equipped with a stem valve for faster inflation/deflation. Follow these instructions to properly inflate/deflate the tube using the valve.



1. Secure the valve by firmly screwing it into the base, then lift off both parts of the valve (the clear plug and the black cap) so that the valve is fully open.
2. To inflate, use a foot pump or air pump. An air pump is included, but you may also use a foot pump if you desire. If you have neither of these, you can use a hairdryer set to COOL, but you should ideally try to use a foot/air pump that is designed for this purpose. Connect the pump to the valve, and inflate until the towable tube is 90% inflated.
3. Once the tube is mostly inflated, close the black cap.
4. Use a foot/air pump to inflate the tube the rest of the way.
5. Seal the valve with the clear plug.
6. To deflate the unit, simply remove both plugs so the valve is fully open.

If you notice air leakage, make sure that

1. The valve and cap are both screwed in straight and firmly tightened.
2. The valve is not cross-threaded.

Make sure not to over-inflate the tube. The tube should be full, but not excessively firm. If the tube is left in direct sunlight, the air inside it will heat and expand inside the PVC tube. This expansion can cause over-inflation or rupture the tube if there is too much air in the unit. Use caution at all times.

CARE AND MAINTENANCE

General Maintenance

As an outdoor product, the towable tube is subject to wear and deterioration. Inspect for signs of fabric failure; weak or torn surfaces must be repaired promptly.

To keep the product clean: wipe the tube or air pump using a dry cloth or a cloth dampened with a neutral, non-flammable, and nontoxic cleaning and sanitizing solution, or pure water.
This product should never be stored wet. Always allow it to dry fully before storage.

Air Pump Maintenance

The air pump must be unplugged before servicing.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

The air pump should be periodically examined for potentially unsafe conditions such as a damaged or frayed power cord, plug, housing, or parts. In the event such damage is found, the product should not be used until properly repaired. If these checks are not carried out, the product could become a hazard.

The air pump does not require any lubrication and has no user serviceable parts. Do not attempt to service the air pump.

Do not immerse the fan in water. To clean, wipe with a damp cloth.

Regularly check the intake and output openings and keep free of dirt, leaves, etc.

When not in use, store the air pump indoors in a dry place.

Store the air pump upright on a stable surface.

Loosely coil the cord and place it beside the air pump.

When in use, do not place the cord across high-traffic areas, water sources, or similarly damp areas.

Place the air pump in an area where it will not draw in dirt or leaves.

Disposal Instructions

Disassemble and dispose of the equipment in such a manner that no hazardous conditions exist at the time the equipment is discarded.

The air pump should be returned to a collection center.

WARRANTY

LIMITED WARRANTY ON SUNNY AND FUN® 2-PERSON TOWABLE TUBE

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE. WE WARRANT THAT DURING THE WARRANTY PERIOD, THE PRODUCT WILL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP.

LIMITATION OF LIABILITY

TO THE EXTENT NOT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. EXCEPT FOR THE EXPRESS WARRANTIES CONTAINED IN THIS LIMITED WARRANTY STATEMENT AND TO THE EXTENT NOT PROHIBITED BY LAW, WE DISCLAIM ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW DISCLAIMERS OF IMPLIED WARRANTIES, SO THIS DISCLAIMER MAY NOT APPLY TO YOU. TO THE EXTENT SUCH WARRANTIES CANNOT BE DISCLAIMED UNDER THE LAWS OF YOUR JURISDICTION, WE LIMIT THE DURATION AND REMEDIES OF SUCH WARRANTIES TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

OUR RESPONSIBILITY FOR DEFECTIVE GOODS IS LIMITED TO REPAIR, REPLACEMENT OR REFUND AS DESCRIBED BELOW IN THIS WARRANTY STATEMENT.

WHO MAY USE THIS WARRANTY? C&A Marketing, Inc. located at 114 Tived Lane East, Edison, NJ ("we") extend this limited warranty only to the consumer who originally purchased the product ("you"). It does not extend to any subsequent owner or other transferee of the product.

WHAT DOES THIS WARRANTY COVER? This limited warranty covers defects in materials and workmanship of the Sunny and Fun® 2-person towable tube (the "product") for the Warranty Period as defined below.

WHAT DOES THIS WARRANTY NOT COVER? This limited warranty does not cover any damage due to: (a) transportation; (b) storage; (c) improper use; (d) failure to follow the product instructions or to perform any preventive maintenance; (e) modifications; (f) unauthorized repair; (g) normal wear and tear; or (h) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

WHAT IS THE PERIOD OF COVERAGE? This limited warranty starts on the date of your purchase and lasts for one year (the "Warranty Period"). The Warranty Period is not extended if we repair or replace the product. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

WHAT ARE YOUR REMEDIES UNDER THIS WARRANTY? With respect to any defective product during the Warranty Period, we will, at our sole discretion, either: (a) repair or replace such product (or the defective part) free of charge or (b) refund the purchase price of such product if an exchange unit cannot be provided.

HOW DO YOU OBTAIN WARRANTY SERVICE? To obtain warranty service, you must contact us at 1-833-217-4422 or by email at info@supportcbp.com during the Warranty Period to obtain a Defective Merchandise Authorization ("DMA") number. No warranty service will be provided without a DMA number and return shipping costs to our facilities shall be assumed by you, the purchaser. Shipping costs of the replacement unit to you shall be assumed by us.

QUESTIONS OR CONCERNS? WE WANT TO HEAR FROM YOU!

info@supportcbp.com
833-217-4422

SUNNY & FUN is a trademark of C&A IP Holdings, LLC in the U.S.

All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement or approval.

Distributed by C&A Marketing, Inc. 114 Tived Lane East, Edison, NJ 08837 USA. ©2020. C&A IP Holdings, LLC. All rights reserved. Made in China.