

ASSEMBLY AND INSTALLATION INSTRUCTIONS

ASC4

4 STEP, REMOVABLE, FOLDING
PONTOON LADDER

ASC5

5 STEP, REMOVABLE, FOLDING
PONTOON LADDER

- Unfold ladder.
- Mark on your deck where you will drill two 1-1/2" diameter holes.
- Make sure to inspect under deck for crossbeams before drilling.
- After drilling two 1-1/2" diameter holes place cups in holes.
- Secure cups with provided screws.

EXTRA CUPS: EFD or 37123

SAFETY Any ladder can be dangerous if installed or used improperly

- ALWAYS**
- Face ladder when going up or down
 - Step in the center of ladder steps, not on either side
 - Restrict use of the ladder to one person at a time
 - Check all steps and hardware before using
 - Keep fingers and toes clear of pinch points
 - Avoid diving or jumping from ladder
 - Fold ladder before moving boat

