

TempMinder® MRI-122AG

Functions:

- Time w/Alarm & Snooze
- Indoor temperature (-10C to 50C/-14°F to 122°F)
- Outdoor temperature (-50C to 70C/-58°F to 158°F)
- Power: DC 3V
- Accuracy: ± 1°C, 2°F
- Precision: 0.1°C, 0.1°F

Getting Started:

- A) The numbers will not change unless you remove the static label covering the front display as well as the clear plastic insulation strip sticking out the back of the unit. The insulation strip was inserted so that the batteries did not drain prior to you taking it home!
- B) So, remove the strip. If the unit does not immediately “BEEP”, remove the battery cover and press on both batteries. This will confirm their proper installation and connection. Replace the battery cover. In a year or so, you’ll need to replace the two LR1130/AG10 button cells. When you do, be sure the + side is up. To remove the batteries, use a small metal (pointed) tool like a screw driver or straightened paper clip (sorry, not included).
- C) At this point you should see the indoor and outdoor temperatures as well as 0:00 on the clock. Please note due to variances in electronic components, the two temperatures will rarely be exactly the same (even though the probe is indoors at the moment).

D) Setting the Time:

- Press & hold “set” button for 3 seconds
- Press “up” button to select 12hr or 24hr mode
- Press “set” to confirm
- Hour will flash – press “up” or “down” to reach the desired hour
- Press “set” to confirm
- Minutes will flash – press “up” or “down” to reach the desired minute
- Press “set” to confirm

That’s it! If you did that on the first try, congratulations – you’re a programming expert.

E) Setting the Alarm:

- Press and release the “Mode” button once. You will see “Alarm” above where the minutes should be.
- Press and hold “Set” for 3 seconds – press “up” or “down” to reach the desired hour.
- Press “set” to confirm
- Press “up” or “down” to reach the desired minute
- Press “set” to confirm
- Press “mode” to return to normal time.

F) Alarm Functions:

You should notice a small “bell” icon above the time display. When the alarm is activated, press the SNZ button for an extra 8 minutes of REM sleep. Pressing any other button will turn off the alarm.

To cancel the alarm press and hold the SNZ button for 3 seconds. The small “bell” icon will disappear. To re-instate the alarm, press and hold the SNZ button again (3 seconds). The “bell” icon will re-appear.

G) Temperature Functions:

- Press the “down” button to switch between C and F
- Press “up” to see the Maximum indoor and outdoor temperatures (since last cleared)
- Press “up” again to see the Minimum indoor and outdoor temperatures (since cleared)
- Press “up” again to return to a normal display (or wait for 10 seconds)
- To “clear” the Min/Max memories, press “up” to display the Maximums, then press “set” to clear. Repeat to clear the Minimum record.

The Probe may be hung out a window, placed inside a refrigerator, freezer or even in an aquarium! If you hang it out a window, keep it out of direct sunlight as that can increase the temperature by up to 20 degrees. Shouldn’t matter if you are monitoring in C or F. Twenty degrees not correct!

WARRANTY: This product is guaranteed against manufacturing defects (not including batteries) for a period of one year. Should it fail, return it to the address below (with a copy of your receipt). If you drop it, or your dog chews it up, please just buy a new one!!!! ENJOY

Minder Research Inc

P.O. Box 47, Port Salerno, FL 34992

www.MinderResearch.com

info@MinderResearch.com

©2010 The Minder Research Incorporated